

W5747 Lost Arrow Road • Fond du Lac, WI 54937 • Ph(920)922-9168 • F(920)922-1429 www.tecre.com

2-1/4", 1-1/2", or 1-3/4" Key Chain Button Making Supplies: How to Make a Key Chain Button

- 1. Identify the crimp die and the pickup die of the button maker machine.
- 2. Rotate the die table so that the crimp die is positioned under the upper die.
- 3. Insert a shell into the pickup die. Place the graphic on the shell. Place the mylar on top of the graphic.
- 4. Rotate the die table one-half turn clockwise until the die table stop is against the outer column.
- 5. Pull the handle down as far as it will go and raise it back up to its rest position.
- 6. Place a flat key chain back into the crimp die with the sharp side up.
- 7. Rotate the die table one-half turn counterclockwise until the die table stop is against the the outer column of the button maker machine.
- 8. Pull the handle down as far as it will go and raise it back up to its rest position.
- 9. Rotate the die table and remove the button.
- 10. Snap in one of the three key chain options into the open slot on the side of the flat back to finish the key chain.

