



W5747 Lost Arrow Road • Fond du Lac, WI 54937 • Ph(920)922-9168 • F(920)922-1429  
www.tecre.com

## Magnet Button Making Supplies: How To Make a Magnet Button

1. Identify the crimp die and the pickup die of the button maker machine.
2. Rotate the die table so that the crimp die is positioned under the upper die.
3. Insert a shell into the pickup die. Place the graphic on the shell. Place the mylar on top of the graphic.
4. Rotate the die table one-half turn clockwise until the die table stop is against the outer column.
5. Pull the handle down as far as it will go and raise it back up to its rest position.
6. Place a flat back (for 2-1/4", 3" and 3-1/2") or an unpinned back (for 1-1/4", 1-1/2", 1-3/4", 2", 2-3/8", 2-1/2", 3" B.A.M. and 4") into the crimp die with the sharp edge facing up. (If you are making a 2" magnet button, it will not matter which side is up).
7. Rotate the die table one-half turn counterclockwise until the die table stop is against the outer column.
8. Pull the handle down as far as it will go and raise it back up to its rest position.
9. Rotate the die table clockwise again to remove the finished button.
10. Apply the adhesive peel and stick magnet to the back of the button.

